



Firmware for SL60-401 / SL60-501 / SL60-4010

Release notes

To: Whom it may concern
Attachments: -

Firmware Version 1.07 (Rev 1206)

- System:
 - o Stability improvements of the system.
 - o **Default password has changed (default password is “password” instead of “sl60”)**
→ Please note that a firmware upgrade will recover your current settings, the new default password will be set only if a reset is triggered by the user
 - o Added a rescue firmware upgrade mechanism in the boot loader
- Web GUI:
 - o Improved accuracy of indicated RSSI value
 - o Changed appearance of alignment bar
 - o Some corrections and adaptations in nomenclature to improve ease of use

Firmware Version 1.06 (Rev 923)

- Web GUI:
 - o Modulation scheme can now be changed on the air interface page independently of the SL60 model (exception: SL60-4010)
 - o Added broadcast/multicast storm protection functionality (service page)
 - o Improved statistics page
 - o Improved log file (performance log)
 - o Added reset button on statistics page
- SNMP:
 - o Added SNMP object “sencityAuxVoltage” to the H+S MIB
- Fixed bugs:
 - o “Web GUI: Missing reset button on statistics page” → FIXED
 - o “Web GUI: Wrong “Network Datarate” displayed on overview page” → FIXED

Firmware Version 1.01 (Rev 634)

- NTP implemented
- SSH and Telnet are disabled by default (only needed for service purposes)
- Firmware upgrade can be done by file upload through web GUI on the system page
- Web GUI:
 - o SNMP section has moved to system page
 - o Some corrections and adaptations in nomenclature to improve ease of use
 - o Re-alignment of some GUI elements (e.g. buttons) to improve ease of use
 - o Display of status information box has been improved
 - o Remote terminal values are displayed on the overview page
 - o Added reboot button on system page
- SNMP:
 - o SNMP objects of the interfaces group (IF-MIB) implemented
 - o SNMPv3 (beta status)
- Fixed bugs:
 - o “Setting the terminal to factory default, might set wrong default password and username (sl60 / admin instead of admin / sl60)” → FIXED
 - o “If VLAN is enabled the default gateway is not set properly.” → FIXED
 - o “SNMP: no replies from SNMP objects of the interfaces group MIB (IF-MIB)” → FIXED